DESKLINE®
IMPROVING ERGONOMICS

LINAK Envikta

User Manual



LINAK.COM/DESKLINE

LINAK®
WE IMPROVE YOUR LIFE

Contents

Preface 3
Important safety information 4
Informations importantes en matière de sécurité 5
Safety instructions 6
Important safety instructions 6
General 6
Before start-up 8
During operation 8
Before troubleshooting 8
Declaration of Conformity 9
The system 10
Intended use 10
Warranty 10
Installation 11
Parts 12
Assembling the desk 13
Connection 14
Operation 15
Maintenance 16
Cleaning the desk panel 16
Disassembly 17
Technical data 18
Product label 18
Troubleshooting 19
Troubleshooting guide 19
Error codes 19
Repair and disposal 20
Contacts 21

Preface

Dear User,

Congratulations on your LINAK desk.

LINAK desks are high-tech products based on many years of experience in manufacturing components for desks.

This User Manual provides installation and operation instructions, as well as relevant safety information.

There is a warranty on this product, see Warranty. This warranty, however, is subject to correct use in accordance with the specifications, maintenance being done correctly, and any repairs being carried out at a service centre, which is authorised to repair LINAK products.

This User Manual has been written based on the present technical knowledge.

LINAK A/S

Important safety information

Safe use of the system is possible only when this document is read completely and the instructions contained are strictly observed.

Failure to comply with instructions marked with the "NOTICE" symbol may result in serious damage to the system or one of its components.

Read all instructions before using this product.

Important safety information on LINAK® products can be found under the following heading(s):



DANGER

Failure to comply with these instructions will result in severe personal injury.



WARNING

Failure to comply with these instructions may result in severe personal injury.



CAUTION

Failure to comply with these instructions can result in minor personal injury.



NOTICE

Failure to comply with these instructions can result in property damage.

READ AND SAVE THESE INSTRUCTIONS

Informations importantes en matière de sécurité

Une utilisation sûre du système n'est possible que lorsque ce document est lu dans son intégralité et que les instructions qu'il contient sont strictement respectées.

Le non-respect des instructions marquées du symbole "AVIS" peut entraîner de graves dommages au système ou à l'un de ses composants.

Lisez toutes les instructions avant d'utiliser ce produit.

Des informations de sécurité importantes sur les produits LINAK® sont disponibles dans la ou les rubriques suivantes :



DANGER

Le non-respect de ces instructions entraînera des blessures graves.



AVERTISSEMENT

Le non-respect de ces instructions peut entraîner des blessures graves.



ATTENTION

Le non-respect de ces instructions peut entraîner des blessures corporelles légères.



AVIS

Le non-respect de ces instructions peut entraîner des dommages matériels.

LIRE ET CONSERVER CES INSTRUCTIONS

Safety instructions

Important safety instructions

General



DANGER

Plugged-in products

Risk of electric shock

- Always unplug this product from the electrical outlet before assembling, disassembling, cleaning, or servicing.
- Only use the product indoors in dry locations.



WARNING

General precautions

Risk of burns, fire, electric shock, or injury to persons

- Unplug from outlet before putting on or taking off parts.
- It is important that everyone who is to connect, install, or use the systems has the necessary information and access to this User Manual. Follow the instructions for mounting - there is a risk of injury if these instructions are not followed.
- Close supervision is necessary when this product is used by or near children, invalids, or disabled persons.
- If there is visible damage to the product, do not install or use the product.
- Ensure that the cable and the plug are not damaged, and keep the cable away from heated surfaces.
- Use this product only for its intended use as described in this User Manual.
  Do not use attachments not recommended by the manufacturer.
- Never insert any object into any opening.
- During construction of applications in which the system is to be fitted, there must be no risk of personal injury, for example squeezing of fingers or arms.
- Do not open the product.



CAUTION

Objects above and below the application

Risk of personal injury and material damage

- Ensure free space above and below the application to avoid entrapment and blocking the movement in either direction.

Observe the minimum distances shown below.




Figure 1 Minimum distance to objects nearby the desk




Figure 2 Minimum distance between two adjacent desks

Before start-up

- Make sure that the system has been assembled as instructed in this User Manual.
- Only connect the system to the mains voltage stated on the product label.
- Always use the supplied power cable.
- Position the desk near the power socket to ensure that the mains cable stays in the socket - even when the desk is adjusted to maximum height.
- Only connect to power when fully assembled and set up.

During operation

- If the system makes unusual noise or smells, unplug the mains cable immediately.
- Observe the maximum load capacity (equally distributed):
  Dynamic: 80 kg
  Static: 80 kg
- Duty cycle: 5 %, max. 1 minute continuous use at full load followed by 19 minutes pause.
- Take care that the cables are not damaged.

Before troubleshooting

- Stop the system.
- Unplug the power cable.
- Relieve the system of any loads, which may be released during the work.
- Review the assembly instructions to confirm that the appropriate critical components and accessories are being used with this product.

CAUTION

Load on the desk

Risk of injury to persons and of malfunction

- Do not overload the frame.
- Place heavy load centrally on the desk.
- Do not use the desk as a work bench.
- Do not use the frame for lifting persons.
- Do not stand on the desk while it is driving up or down.

NOTICE

Duty cycle

Risk of malfunction

- Do not exceed the duty cycle.

Declaration of Conformity

LINAK A/S
Smedevænget 8
DK - 6430 Nordborg

Herewith declares under our sole responsibility that LINAK DESKLINE® products as characterized by the following type:

Envikta

complies with Machinery Directive **2006/42/EC** (OJ L 157 9.6.2006, p. 24) according to the standard:
EN 60335-1:2012+AC:2014+A11:2014+A13:2017+A15:2021
EN ISO 13854:2019

complies with parts of EMC Directive: **2014/30/EU** (*OJ L 96, 29.3.2014, p. 79–106)* according to following standards:
EN 61000-6-1:2007,
EN 61000-6-3:2007+A1:2011+AC:2012

complies with regulation 2023/826/EU (*OJ L 103, 18.4.2023, p. 29–47*): laying down ecodesign requirements for off mode, standby mode, and networked standby energy consumption of electrical and electronic household and office equipment pursuant to Directive 2009/125/EC of the European Parliament and of the Council and repealing Commission Regulations (EC) No 1275/2008 and (EC) No 107/2009 according to the standards:
EN 50564:2011,

complies with Directive **2011/65/EU** of the European Parliament and of the Council of 8 June 2011 on the restriction of the use of certain hazardous substances in electrical and electronic equipment (*OJ L 174, 1.7.2011, p. 88–110*) and Directive **2015/863** (*OJ L 137, 4.6.2015, p. 10–12*) (amending Annex II to Directive 2011/65/EU) according to the standard:
EN IEC 63000:2018

Nordborg, 2025-08-22

Signature present in original document.

Signed: Dragan Macura (Regulatory Compliance Manager)

The system

The *Envikta* desk is a complete height-adjustable desk ideal for small home offices. It offers many advantages. All components are supplied in one package making transport particularly easy. The cables are integrated into the top frame for a clear design. The top frame and desk panel are pre-assembled, and only the legs need to be clicked into place - convenient and simple assembly.

Intended use

This product is intended for use indoors in household and commercial usage areas.

DANGER

Wet areas

Risk of electric shock

- Do not use the product in wet areas.

Warranty

Under normal use conditions, this product carries a 5-year (60 months) warranty against defects in manufacturing (metal and mechanical parts including motor and electric components) from the date of purchase.

WARNING

- This appliance may be used by children aged 8 years and older and by persons with reduced physical, sensory, or mental capabilities, or with limited experience and knowledge, provided they have received supervision or instruction regarding safe use of the appliance and understand the associated hazards.
- Children must not play with the appliance. Cleaning and user maintenance must not be performed by children without supervision.

For US and Canadian markets only

- Persons who lack the necessary experience or knowledge must not use the product unless they have received appropriate instruction or supervision from a person responsible for their safety.
- Persons with reduced physical, sensory, or mental capabilities must not use the product unless they are under supervision or have been instructed in its safe use by a person responsible for their safety.
- Children must be supervised to ensure that they do not play with the product.
- Before operating the application, ensure that it can move freely without creating a risk to the operator or bystanders.

Installation

A mounting instruction video is available here:

Check the packaging and all delivered items for visible damage.

WARNING

Plastic bags

Risk of suffocation

- Keep the plastic bags away from babies and children.

WARNING

Mounting the legs

Risk of squeezing fingers

- Be careful when mounting the columns. Fingers may get squeezed or crushed.

WARNING

Liquid in desk panel

Risk of injury to persons if the desk starts running unexpectedly

- Place the desk panel where liquids are unlikely to run into the desk panel.

CAUTION

Flipping the desk over

Risk of injury to persons and of damaged desk

- Be careful not to drop the desk when flipping it over.

CAUTION

Heavy parts and sharp edges

Risk of injury to persons due to crushing or cutting

- Be careful when handling the desk parts.

CAUTION


Tilting table

Risk of injury to persons

- Ensure that the columns are mounted correctly and locked by the pawl.

Parts

The *Envikta* desk comes in a box containing three items - a tabletop *(with pre-mounted beam and connected mains cable)* and two legs.




Letter	Parts
A	Tabletop
B	Beam
C	Legs
D	Mains cable
E	Disassembly tool

Figure 3 *Envikta* parts

Assembling the desk


1. Ensure that the legs are completely retracted.




If the leg extends when turned upside down, press it by hand until it is fully retracted.

Be careful when mounting the legs. Fingers may get squeezed or crushed.

2. Tilt the legs and place them correctly on the beam using the guiding notches.



3. Fix the leg to the beam by pressing down until a "click" is heard and **both** pawls lock the leg in the correct position.




Check that both pawls are visible after mounting the legs. Otherwise, remove the leg and try again (see Disassembly, steps 4, 5, and 6).

4. Flip the desk over.



Connection

1. Connect to the mains supply.




Your desk is now ready for use.

Operation

The desk panel is divided into 3 sections; the display and sections for up/down drive and for memory drive. The two arrows are used for up/down drive, and the other four buttons are used for memory drive.

∧	Up
∨	Down
•	Memory 1
••	Memory 2
•••	Memory 3
S	Store memory



Normal operation:
To run the desk up or down, press the ⌃ or ⌄ button and keep it pressed until the desk reaches the desired height. The display will show the actual height while the desk is moving and continue to show the height of the desk for 10 seconds when the desk stops.

Storing a memory position (⊙⊙⊙Ⓢ):
Drive the desk to the desired height. Press the Ⓢ button and the display will flash S for 2 sec. While the S is displayed, press one of the memory buttons. When the display shows 1, 2 or 3, the position is saved.

To abort a storing sequence, press the ⌃ or ⌄ button while the "S" is flashing, or wait the 3 seconds until the display shows the desk height again.

Drive to a stored position (⊙⊙⊙):
Press one of the memory buttons and the system will start driving to the desired memory position. Keep pressing the button until the position is reached and the desk stops.

Maintenance

Clean dust and dirt from the outside of the system at appropriate intervals and inspect for damage and breaks.

Inspect connections, cables, and plugs without disconnecting, and check functioning as well as fixing points.

CAUTION


Loose screws

Risk of loss of stability


- Check for loose screws on a regular basis. Fasten if necessary.

Cleaning the desk panel

Clean your desk panel with a soft damp cloth. Universal cleaning detergents may be used.



For disinfection of the desk panel, use a 70 percent isopropyl alcohol either as a wipe or add a small amount to a soft cloth.







CAUTION

Risk of damaging the desk panel

The desk panel is not a sealed unit and there are electronics inside it.

- Ensure that liquids or moisture does not enter an opening. It may damage the PCB and ruin the desk panel.
- Avoid spraying the cleaning agent or disinfectant directly on the desk panel.





- Cleaning agents and disinfectants must not be highly alkaline or acidic (pH value must be 6 to 8), and they must not contain bleach or chlorine.
- Do not use hand sanitizer gel as a cleaning agent.

Disassembly

For disassembling the *Envikta* desk, use the disassembly tool supplied with the desk.




Figure 4 Disassembly tool (pins)






Figure 5 Disassembly tool (triangular plates)


1. Drive the desk to its minimum height so the legs are completely retracted.
2. Disconnect from the mains supply.
3. Flip the desk over.
4. Place the disassembly tool with the pins in the intended holes in the cantilever and the triangular plates towards the leg.
5. Press straight down to make the pawl release the leg.
6. At the same time press the disassembly tool down and tilt the leg to remove it from the beam.



Step 4



Step 5



Step 6

Technical data



Parameter	Specification
Colours	Tabletop: White, grey or oak Legs and feet: Black
Control	Up/down 3 memory positions
Tabletop dimensions	1120 x 770 mm
Weight	Approximately 24 kg
Minimum height	72 cm
Maximum height	123 cm
Maximum load	80 kg
Maximum speed	38 mm/s
Duty cycle	5 % (1 minute ON / 19 minutes OFF)
Mains voltage	230 V, 50-60 Hz
Standby power consumption	0.1 W
Time before entering standby mode	< 1 minute
Ambient temperature	Operation: 10 to 40 °C Storage -10 to +70 °C

Product label



Troubleshooting

Troubleshooting guide

Issue	Remedy
The display is turned off and I cannot adjust the desk.	Check that the mains cable is plugged in properly. Ensure that the mains cable is inserted in the cable hook. 
The display shows incorrect height.	It is possible to change the displayed height. Press the ⌃⌄ buttons at the same time and keep them pressed for 5 seconds. The display shows three dashes (- - -). When the display reverts to showing the height, the displayed height can be adjusted using one of the ⌃⌄ buttons until the correct height is displayed. Press Ⓢ to save the new value, or wait 5 seconds for the panel to return to normal operation (after a brief flash).
The desk legs are unevenly extracted (desk tilted) 	Initialise the desk 1. Hold the ⌄ button on the desk panel to ensure that the desk is retracted to its lower limit (either fully retracted, or retracted to a configured lower limit). 2. Briefly release the ⌄ button. 3. Press and hold the ⌄ button for 5 seconds. Wait until all desk movement has stopped, then release. If initialisation is successful, you should see a slight up/down "handshake" movement of the desk legs. The desk panel will display E01 during this part of the procedure.

Error codes

Error code	Description	Remedy
E01	Position lost. The desk does not know its current position.	Initialise the desk, see Troubleshooting section above.
E90	The system temperature is high and operation is not allowed.	Allow the system to cool down. Leave the system powered on and do not operate for 2 hours.
E93	The anti-collision sensor was triggered.	Remove any obstacles causing the desk drive to stop and adjust the desk height again.

Repair and disposal

WARNING

Opening the product

Risk of injury to persons and of malfunction

- Do not open the product unless you are authorised to do so.

Only an authorised LINAK® service centre should repair the LINAK products. Products to be repaired under warranty must be sent to an authorised LINAK service centre.

In order to avoid the risk of malfunction, all product repairs must only be carried out by an authorised LINAK Service shop or repairers, as special tools and parts must be used.

If a product is opened by unauthorised personnel there is a risk that it may malfunction at a later date.

LINAK systems or components may be disposed of, possibly by dividing them into different waste groups for recycling or combustion.

We recommend that our product is disassembled as much as possible at the disposal and that you try to recycle it. LINAK systems or components should be disposed of in accordance with the environmental regulations applicable in the respective country.

Almost all our cast plastic parts are supplied with an interior code for plastic type and fibre contents, if any.

Contacts

FACTORIES

Denmark - Headquarters
LINAK A/S
Phone: +45 73 15 15 15
Fax: +45 74 45 80 48
Fax (Sales): +45 73 15 16 13
Web: www.linak.com

China
LINAK (Shenzhen) Actuator Systems, Ltd.
Phone: +86 755 8610 6656
Phone: +86 755 8610 6990
Web: www.linak.cn

Slovakia
LINAK Slovakia s.r.o.
Phone: +421 51 7563 444
Web: www.linak.sk

Thailand
LINAK APAC Ltd.
Phone: +66 33 265 400
Web: www.linak.com

USA
LINAK U.S. Inc.
Americas Headquarters
Phone: +1 502 253 5595
Fax: +1 502 253 5596
Web: www.linak-us.com
www.linak-latinamerica.com

SUBSIDIARIES

Australia
LINAK Australia Pty. Ltd
Phone: +61 3 8796 9777
Fax: +61 3 8796 9778
E-mail: sales@linak.com.au
Web: www.linak.com.au

Austria
LINAK Zweigniederlassung - Österreich (Wien)
Phone: +43 (1) 890 7446
Fax: +43 (1) 890 744615
E-mail: info@linak.de
Web: www.linak.at - www.linak.hu

Belgium
LINAK Actuator-Systems NV/SA
(Belgium & Luxembourg)
Phone: +32 (0)9 230 01 09
E-mail: beinfo@linak.be
Web: www.linak.be - www.fr.linak.be

Brazil
LINAK Do Brasil Comércio De Atuadores Ltda.
Phone: +55 (11) 2832 7070
Fax: +55 (11) 2832 7060
E-mail: info@linak.com.br
Web: www.linak.com.br

Canada
LINAK Canada Inc.
Phone: +1 502 253 5595
Fax: +1 416 255 7720
E-mail: info@linak.ca
Web: www.linak-us.com

Czech Republic
LINAK C&S s.r.o.
Phone: +42 058 174 1814
Fax: +42 058 170 2452
E-mail: info@linak.cz
Web: www.linak.cz - www.linak.sk

Denmark - International
LINAK International
Phone: +45 73 15 15 15
E-mail: info@linak.com
Web: www.linak.com

Denmark - Sales
LINAK Danmark A/S
Phone: +45 86 80 36 11
Fax: +45 86 82 90 51
E-mail: linak@linak-silkeborg.dk
Web: www.linak.dk

Finland
LINAK OY
Phone: +358 10 841 8700
E-mail: linak@linak.fi
Web: www.linak.fi

France
LINAK France E.U.R.L
Phone: +33 (0) 2 41 36 34 34
Fax: +33 (0) 2 41 36 35 00
E-mail: linak@linak.fr
Web: www.linak.fr

Germany
LINAK GmbH
Phone: +49 6043 9655 0
Fax: +49 6043 9655 60
E-mail: info@linak.de
Web: www.linak.de

India
LINAK A/S India Liaison Office
Phone: +91 120 4531797
Fax: +91 120 4786428
E-mail: info@linak.in
Web: www.linak.in

Ireland
LINAK UK Limited (Ireland)
Phone: +44 (0)121 544 2211
Fax: +44 (0)121 544 2552
+44 (0)796 855 1606 (UK Mobile)
+35 387 634 6554 (Rep.of Ireland Mobile)
E-mail: sales@linak.co.uk
Web: www.linak.co.uk

Italy
LINAK ITALIA S.r.l.
Phone: +39 02 48 46 33 66
Fax: +39 02 48 46 82 52
E-mail: info@linak.it
Web: www.linak.it

Japan
LINAK K.K.
Phone: 81-45-533-0802
Fax: 81-45-533-0803
E-mail: linak@linak.jp
Web: www.linak.jp

Malaysia
LINAK Actuators Sdn. Bhd.
Phone: +60 4 210 6500
Fax: +60 4 226 8901
E-mail: info@linak-asia.com
Web: www.linak.my

Netherlands
LINAK Actuator-Systems B.V.
Phone: +31 76 5 42 44 40 /
+31 76 200 11 10
E-mail: info@linak.nl
Web: www.linak.nl

New Zealand
LINAK New Zealand Ltd
Phone: +64 9580 2071
Fax: +64 9580 2072
E-mail: nzsales@linak.com.au
Web: www.linak.com.au

Norway
LINAK Norge AS
Phone: +47 32 82 90 90
E-mail: info@linak.no
Web: www.linak.no

Poland
LINAK Polska
LINAK Danmark A/S (Spólka Akcyjna)
Phone: +48 22 295 09 70 /
+48 22 295 09 71
E-mail: info@linak.pl
Web: www.linak.pl

Republic of Korea
LINAK Korea Ltd.
Phone: +82 2 6231 1515
Fax: +82 2 6231 1516
E-mail: info@linak.kr
Web: www.linak.kr

Slovakia
LINAK Slovakia S.R.O.
Phone: +421 51 7563 444
Web: www.linak.sk

Spain
LINAK Actuadores, S.L.u
Phone: +34 93 588 27 77
Fax: +34 93 588 27 85
E-mail: esma@linak.es
Web: www.linak.es

Sweden
LINAK Scandinavia AB
Phone: +46 8 732 20 00
Fax: +46 8 732 20 50
E-mail: info@linak.se
Web: www.linak.se

Switzerland
LINAK AG
Phone: +41 43 388 31 88
E-mail: info@linak.ch
Web: www.linak.ch - www.fr.linak.ch
www.it.linak.ch

Taiwan
LINAK (Shenzhen) Actuator systems Ltd.
Taiwan Representative office
Phone: +886 2 272 90068
Fax: +886 2 272 90096
E-mail: sales@linak.com.tw
Web: www.linak.com.tw

Turkey
LINAK İth. İhr. San. ve Tic. A.Ş.
Phone: + 90 312 4726338
Fax: + 90 312 4726635
E-mail: info@linak.com.tr
Web: www.linak.com.tr

United Kingdom
LINAK UK Limited
Phone: +44 (0)121 544 2211
Fax: +44 (0)121 544 2552
E-mail: sales@linak.co.uk
Web: www.linak.co.uk

DISTRIBUTORS

Argentina
Novotec Argentina SRL
Phone: 011-4303-8989 / 8900
Fax: 011-4032-0184
E-mail: info@novotecargentina.com
Web: www.novotecargentina.com

Colombia
MEM Ltda
Phone: +[57] (1) 334-7666
Fax: +[57] (1) 282-1684
E-mail: servicioalcliente@memltda.com.co
Web: www.mem.net.co

India
Mechatronics Control Equipments India Pvt Ltd
Phone: +91-44-28558484, 85
E-mail: bala@mechatronicscontrol.com
Web: www.mechatronicscontrol.com

Indonesia
PT. Himalaya Everest Jaya
Phone: +6 221 544 8956 /+6 221 544 8965
Fax: +6 221 619 1925
Fax (Sales): +6 221 619 4658
E-mail: hejplastic-div@centrin.net.id
Web: www.hej.co.id

Israel
NetivTech LTD
Phone: +972 55-2266-535
Fax: +972 2-9900-560
Email: info@NetivTech.com
Web: www.netivtech.com

Singapore
Servo Dynamics Pte Ltd
Phone: +65 6844 0288
Fax: +65 6844 0070
E-mail: servodynamics@servo.com.sg

South Africa
Industrial Specialised Applications CC
Phone: +27 011 466 0346
E-mail: gartht@isagroup.co.za
Web: www.isaza.co.za

United Arab Emirates
Mechatronics
Phone: +971 4 267 4311
Fax: +971 4 267 4312
E-mail: mechtron@emirates.net.ae

Terms of use

LINAK® takes great care to provide accurate and up-to-date information about its products. However, it is the responsibility of the user to determine the suitability of LINAK products for any specific application. Due to ongoing product development, LINAK products are subject to continuous modifications and changes. LINAK reserves the right to make such modifications, updates, and changes without prior notice. For this reason, LINAK cannot guarantee the accuracy or current status of printed information about its products.

LINAK uses its best efforts to fulfil orders. However, for the reasons mentioned above, LINAK cannot guarantee availability of any particular product at any given time. LINAK reserves the right to discontinue the sale of any product displayed on its website or listed in its catalogues or in other written material created and produced by LINAK, LINAK subsidiaries, or LINAK affiliates.
All sales are subject to the applicable terms and conditions of sale and delivery available on LINAK websites. LINAK and the LINAK logotype are registered trademarks of LINAK A/S. All rights reserved.

Copyright© LINAK • 2026-11 • LIT-93-02-001 C

LINAK®
WE IMPROVE YOUR LIFE